

## Weigh Bar Kits

Avery Weigh-Tronix Universal Scale Kits can be used to build scales of almost any size and shape for your operation. Platform scales, livestock scales, axle scales, bulk storage scales, stationary feed mixer scales, in addition to other specialty scale applications can be created with our Universal Scale Kits.

Includes: Four Weigh Bars, base and mounting bracket assembly, indicator mounting bracket and installation instructions.

### Universal Scale Kits (Indicator not included)

Part Number	* Maximum Scale Capacity		Individual Weigh Bar Bracket Assembly	Shipping Weight		List Price
	lb	kg		lbs	kg	
20265-0016	30,000	15,000	21619-0025	155	70	\$2,510

Note:

Scale kits can be interfaced with any Avery Weigh-Tronix weight indicator. Avery Weigh-Tronix indicators are priced separately and are not included in scale kit pricing.

### Individual Weigh Bar/Bracket Assembly

When ordering, use the description and part number below of the Weigh Bars suitable for your scale application.

Includes Weigh Bar, top and bottom mounting brackets, and assembly hardware.

Part Number	Description	List Price
21863-0010	(2500 lb / 1250 kg cap.) 1½" (3.81 cm) diameter, gauged 21/8", 30 ft (9.2 m) cord with AWT 5-pin connector (For dimensions refer to outline drawing 20465) Weigh Bar Only - (21594-0271)	\$770
21619-0025	(7500 lb / 3750 kg cap.) 21/8" (5.53 cm) diameter, gauged 21/8", 30 ft (9.2 m) cord with AWT 5-pin connector (For dimensions refer to outline drawing 13339) Weigh Bar Only - (48479-0035)	\$775

Note: Please consult the factory when assembling a special system or when using on a mobile application.